



BRAVO UNIVERSAL MOUNT

Page 1

PART NUMBER: **BR-202BG**

Pre-Installation Tips

The BRAVO Mount is designed to be mounted in one of several orientations on the dash or console of a vehicle. Before installing the BRAVO Mount determine the position where it will work best for the primary user.

Important: The flex pad with 3M adhesive is a one-time stick application. Therefore, it is best to determine the mounting position for the BRAVO Mount prior to installing. Once the flex pad is adhered to the mounting surface, it cannot be repositioned. Be sure to complete all surface preparation steps before installing the BRAVO Mount.

Installation Instructions

Please read all instructions thoroughly before installing these products!

Contents: BRAVO Mount, Surface Preparation Packet, Alcohol Prep Pad

Helpful items to have: Clean dry cloth

Important: Clean the surface where the BRAVO Mount will be installed with the Surface Prep Packet to remove the silicone emulsions such as Armor All®. Do not apply adhesive to leather surfaces. Do not install the BRAVO Mount where it could block your vision, airbags, gear shifter, climate controls, steering wheel, radio controls, or other amenities that may interfere with safe operations of the vehicle.

Step One:

Remove the Locking Plate from the ball of the BRAVO by loosening the collar immediately under the plate and pull off from the ball. Attach your holder or electronics to the lock plate. Double check the best mounting location on the dash or console of the vehicle where the BRAVO is to be installed. Prepare the mounting surface by cleaning the mounting location with the Surface Preparation Packet provided. Wipe an area slightly larger than the flex pad *in only one direction* and do not use a circular motion. Dry the area with a clean, dry cloth. Wipe dry in the same direction as above. Clean the same area with the Alcohol Prep Pad provided in the same fashion. Wipe in the same direction as above, dry with a clean cloth and allow to air dry completely.

Note: The alcohol may leave a film on the surface. Wipe clean with a dry cloth.

Step Two:

Remove the 3M liner from flex pad and adhere the BRAVO to the mounting position. Apply firm pressure to the center and edges of the flex pad for a minimum of 1 minute. Let adhesive cure for 72 hours before attaching the Lock Plate. Ideal installation temperature is between 60° and 80°F.

Step Three:

Snap the plate back onto the ball and snug down the collar. To adjust position, loosen the collar and pivot to desired position, then re-tighten collar. This completes the installation.

Images on back page.



BRAVO

PART NUMBER: BR-202



This shows an iPhone holder attached to the BRAVO.
(Holder and iPhone not included)

Reminder: The BRAVO Mount is one from a series of G3 style mounts that is designed around the 17mm ball. The Lock Plate from this BRAVO will fit onto any VSM G3 style mount or Universal G3 Mount by Pro.Fit International. This allows for more than one mounting option and mounting position for your electronics within your vehicle.

Flex Pad Removal Instructions:

Please read all instructions thoroughly before attempting

- Step 1** If the mounting surface appears to be highly decorative, no removal tools are recommended. Remove by hand and proceed with caution. If the mounting surface is vinyl, a blunt instrument may help to remove the flex pad. A kitchen spoon may work well. Avoid using tools with sharp edges that may damage the mounting surface.
- Step 2** Warm the flex pad with a hair dryer for 2 to 3 minutes. Once the flex pad has been heated, the adhesive will soften. Caution: Too much heat may damage the vehicle or mounting surface. Do not use a commercial heat gun or paint stripping gun as these will create excessive heat.
- Step 3** Lift one edge of the flex pad gently with your fingers or the rounded edge of the spoon. Once enough of the edge is peeled up to grip with your fingers, pull the flex pad gently at a 90 degree angle from the mounted surface until removed.
- Step 4** In most cases there will be no adhesive left on the mounting surface. If adhesive remains, it can be easily removed by rubbing your thumb or finger across the surface repeatedly.

Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit Universal Mount®. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651.688.3588 or 800.388.0073 Fx: 651.688.9876

VIEW INSTRUCTIONS & UPDATES
ONLINE @
WWW.PRO-FIT-INTL.COM