

Components:



TT-35 Adapter



1642 Amps Adapter

This Adapter requires a mounting solution to complete an installation within a vehicle

Pro.Fit International offers several mounting solutions for this Adapter

Components:



TT-35 Adapter



1642 Amps Adapter

This Adapter requires a mounting solution to complete an installation within a vehicle

Pro.Fit International offers several mounting solutions for this Adapter



Installation Instructions Adapter Plate for TomTom One - ver2, ver3 Part # TT-35

Please read all instructions thoroughly before proceeding.

Installation Tips

This TomTom Adapter is produced specifically for the model specified above. *These adapters require a mount*, whether vehicle specific or universal, to be properly installed. The combined adapters attach directly to a VSM, VSM Legend or VSM G3 style mount in addition to any of the universal mounts from Pro.Fit International. The TT-35 Adapter and the 1642 Amps Adapter plate snap together. This should be done only after the 1642 Amps Adapter has been securely bolted to the mounting solution. It is best to preassemble all parts with the TomTom GPS in order to confirm the mounting location and functionality once mounted in the vehicle.

Step One:

After selecting the mount for your vehicle, bolt the 1642 Amps Adapter to the mounting platform. Place the TT-35 Adapter onto the 1642 Amps Adapter and snap down over the 4 tabs to lock into position.

Step Two:

Place the TomTom GPS onto the TT-35 Adapter and slide down until completely engaged.

Step Three:

If the mount selected is adjustable, swivel to the desired position.

Note: Pro.Fit International specializes in vehicle specific and universal mounting solutions for cars, trucks, SUV's and semi trucks. Go to: www.pro-fit-intl.com



Installation Instructions Adapter Plate for TomTom One - ver2, ver3 Part # TT-35

Please read all instructions thoroughly before proceeding.

Installation Tips

This TomTom Adapter is produced specifically for the model specified above. *These adapters require a mount*, whether vehicle specific or universal, to be properly installed. The combined adapters attach directly to a VSM, VSM Legend or VSM G3 style mount in addition to any of the universal mounts from Pro.Fit International. The TT-35 Adapter and the 1642 Amps Adapter plate snap together. This should be done only after the 1642 Amps Adapter has been securely bolted to the mounting solution. It is best to preassemble all parts with the TomTom GPS in order to confirm the mounting location and functionality once mounted in the vehicle.

Step One:

After selecting the mount for your vehicle, bolt the 1642 Amps Adapter to the mounting platform. Place the TT-35 Adapter onto the 1642 Amps Adapter and snap down over the 4 tabs to lock into position.

Step Two:

Place the TomTom GPS onto the TT-35 Adapter and slide down until completely engaged.

Step Three:

If the mount selected is adjustable, swivel to the desired position.

Note: Pro.Fit International specializes in vehicle specific and universal mounting solutions for cars, trucks, SUV's and semi trucks. Go to: www.pro-fit-intl.com

