



**Ford Superduty (2005-2008)  
F250, F350, F450  
PART NUMBER: SDANTPF  
(For NMO style antenna mount)**

**Please Read Complete Instructions Before Installing This Pro.Fit Antenna Mount**

**TOOLS REQUIRED:** 8 mm socket and driver or 8 mm box end wrench  
**PARTS INCLUDED:** Pro.Fit Antenna Mount, 1/2" stainless steel star washer, instructions  
**LOCATION:** Left Front Fender

**Please read** Always check for good continuity between antenna mount and chassis ground. If there is a problem with grounding, place the provided star washer between the NMO antenna mount and vehicle's fender.

**STEP 1.**

Set parking brake. Open hood and locate 8 mm bolt near the back of the left front fender. Remove bolt.

**STEP 2.**

Align the antenna bracket with the bolt hole. Reinstall bolt and tighten.


**STEP 3.**

Install NMO antenna mount on bracket. (NMO not supplied).

This completes the installation of your **Pro.Fit** Antenna Mount for NMO style antenna.



Pro.Fit International, Inc.® may not be held liable for any damage to a vehicle before, during or after the installation or removal of this Pro.Fit VSM®. Pro.Fit may not be held liable for any personal injury resulting from accident or improper installation. Pro.Fit International, Inc.® 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876



© Pro.Fit International, Eagan, MN 2006

