



## Removing Pro.Fit UltiMount™ Flex Pad From Vehicle

The UltiMount™ Flex pad can be easily removed with the following procedure:

1. Remove the UltiMount™ Ball Stem or Extension Arm from the Flex Pad. This will leave only the Flex Pad attached to the vehicle.
2. Evaluate the surface that the Flex Pad is adhered to. If it is highly decorative, no removal tools are recommended, remove by hand and proceed with caution. If the Flex Pad is attached to a vinyl surface, a blunt ( not sharp ) instrument such as a kitchen spoon works well.
3. Warm the Flex Pad with a hair blow dryer for 2 - 3 minutes, if one is accessible. Caution... too much heat may damage the vehicle. Do not use a heat gun or paint stripping gun as these generate excessive heat.
4. After softening the adhesive with the blow dryer, gently lift an edge of the Flex Pad with your fingers or the spoon and pull the Flex Pad at a 90° angle away from the vehicle's surface. When removing with a spoon, use the eating end of the spoon to gently pry the Flex Pad up.
5. In the majority of removals there will be no adhesive left on the vehicle however, if there is, it can be easily cleaned off by rubbing your thumb across the surface several times.

Pro.Fit International Inc. may not be held liable for any damage that may occur due to misuse, negligence, improper use or modification of these described procedures. Please use caution when selecting the blunt instrument, use no sharp edges that may scratch or cut the vehicles surface.

Thank you for selecting Pro.Fit International products!